




Standard Telecaster® 4 Way Switch

Key

-  Solder joint
-  Ground connection. Usually soldered to rear of volume pot

4 Way Selector Positions-


1. Bridge
2. Bridge & Neck in parallel
3. Neck
4. Bridge & Neck in series



Components Used: (click to visit online store)

- [BKP/CTS 280k potentiometer](#)
- [BKP/Jupiter 0.022µF capacitor](#)
- [Standard jack socket](#)
- [Oak-Grigsby 4 way blade switch](#)

IMPORTANT NOTE



Neck cover must have independent ground wire. (original connection from cover to black (coil) wire must be disconnected).



Bare Knuckle
PICKUPS